

# EmbryoSlide culture dishes

First issue 2022.11.03, revised 2024.11.12

# English

# Scope of application

The EmbryoSlide culture dish is intended for the culture of oocytes and embryos in the EmbryoScope incubator.

#### Contraindications

None known.

# Intended users

Embryologists, other laboratory personnel and clinic staff at IVF clinics trained by Vitrolife A/S-certified instructors.

#### Intended patient group

Patients undergoing infertility treatment.

### **Clinical benefits**

- Improved embryo development
- Improved implantation/pregnancy rate
- Reduced pregnancy loss rate.

# Limitations and restrictions on use

The EmbryoSlide culture dish is only intended for use in the EmbryoScope incubator and must be handled by trained personnel according to the instructions in this insert. Any serious incident that has occurred in relation to the culture dish should be reported to Vitrolife and to the competent authority of the Member State in which the user is established.

The EmbryoSlide culture dishes and lids are sterile. The pouches must only be opened in a sterile laminar flow hood, and the culture dish must be covered by the lid when in use.

#### Warnings and precautions

### WARNINGS

The EmbryoSlide culture dish is intended for single use only and MAY NOT be re-used. Any attempt by the user to clean and re-sterilise the culture dish may result in contamination with microorganisms or other risks of device failure.

To avoid contamination with microorganisms, always place the culture dish in a sterile laminar flow hood while loading and generally handling the culture dish. Always label the culture dish appropriately and validate the label when the embryo is transferred either to a new device or to the patient.

#### PRECAUTIONS

Do not use the rinsing wells for incubating embryos as no images are acquired from these wells.

The reservoir and rinsing wells MUST always be covered by a confluent oil layer of 1.4 ml of IVF-grade oil. This prevents the medium from evaporating during incubation.

Evaporation of the medium can change osmolality, which may affect embryo development.

Always place the culture dish in a sterile laminar flow hood while loading it. Take care while loading and handling the culture dish to reduce the risk of spilling any oil or medium.

If ANY oil or medium is accidentally spilled from the culture dish while it is loaded or handled, the embryos MUST be transferred to a new culture dish to prevent them from being adversely affected by the spillage.

In case any oil is spilled on the culture dish outside of the reservoir, gently wipe off the oil by using a lint-free tissue paper. If any oil is present on the lid, the lid must be replaced.

There is a slight variation in how much the temperature decreases in the microwells and rinsing wells during handling: i) First two minutes: The temperature decreases less than 0.1°C in the microwells and approx. 0.7°C in the rinsing wells. ii) Between 2 and 5 minutes: The temperature decreases approx. 0.2°C in the microwells and 0.6°C in the rinsing wells. Always verify the temperature on your own heating stage.

If any bubbles are present in the well or oil layer after preparation, they may block the camera light and compromise image quality. In rare cases, bubbles may dislodge the embryo from the bottom of the microwell.

Any bubbles must be removed carefully and relatively quickly to avoid evaporation of medium.

Take care not to remove any medium when removing the bubbles.

Discard the product according to standard clinical practice for medical hazardous waste when the procedure is finished.

### Product description

The EmbryoSlide culture dish is a single-use sterile dish designed for the culture of embryos in the EmbryoScope incubator.

The EmbryoSlide culture dish contains two types of wells: 12 culture wells in which the embryos reside during incubation and four rinsing wells that are used for rinsing and handling the embryos. The embryos reside in a central depression –

the microwell – inside each culture well. The culture wells are cylindric and have a diameter of 4.09 mm. The microwells are conic with a flat bottom and have a bottom diameter of 0.25 mm. See the illustration on the last page of this insert for an overview of the culture dish.

# Preparing the culture dish

Prepare one culture dish at a time to minimise handling time. Work on a non-heated workbench and use cold medium and oil.

- 1. Remove the culture dish from the pouch in a sterile laminar flow hood.
- Fill all microwells with medium using a micropipette (max. diameter: 200 µm). One filling of the tip will suffice to completely fill all microwells. The tip of the pipette must touch the side of the microwell during filling. Slightly overfill each microwell.
- Use a standard pipette to immediately fill an additional 25 μl of medium into each well. It is important to release the medium from the pipette close to the bottom of the microwell at a constant, not too fast rate.
- 4. Fill each rinsing well with 25  $\mu l$  of medium.
- Load 1.4 ml of oil certified for IVF into the reservoir. Make sure that all culture wells and rinsing wells are covered with a confluent oil layer. Add an additional amount of oil for each well or reservoir not filled with medium.
- 6. Push up any large bubbles with a micropipette and then remove them.
- 7. Cover the culture dish with the lid and equilibrate it overnight.
- 8. Identify and remove any bubbles under a stereo microscope.
- 9. Load embryos into the centre of the microwells using a micropipette.
- 10. Place the culture dish in the EmbryoScope incubator.

# Product name

Culture dishes.

# Product model and specification

Model and specification: FT-S-ES-D, EmbryoSlide.

# Product registration certificate number/product technical requirement number

Product registration certificate number: 国械注进 20202180348

Product technical requirement number: 国械注进 20202180348

# Product features

Sterile

Bacterial endotoxin (LAL experiment) [EU/item] < 20

Mouse in-vitro embryo test (1-cytoplasm mouse  $\ge$  80% embryo) [expanded blastocyst percentage on the fifth day]

All products include the quality inspection analysis report for the corresponding batch number.

#### Product main structure and composition

This product is made of uncoated polystyrene.

# Manufacturing date, expiry date and storage and transportation conditions

Manufacturing date: see the product label. Expiry date: see the product label. Storage conditions: store at room temperature. Transportation conditions: transport at room temperature.

#### Registration applicant/manufacturing organisation, domicile, manufacturing address, production licence number and contact information

Name: Vitrolife A/S Domicile and manufacturing address: Jens Juuls Vej 16, 8260 Viby J, Denmark Production licence number: CVR (DK) 27406793 Telephone: +45 7221 7900 Fax: +45 7221 7901

# Agent/after-sales service company name, address and contact information

Name: Vitrolife (Beijing) Medical Device Co., Ltd. Address: No. 005, Room 1001, Unit 2, 9th Floor, Suite [287], Building 1-3-3001, Yard 33, Guangshun North Street, Chaoyang District, Beijing, China Zip code: 100102 Telephone: +86 10 64036613 Fax: +86 10 64036613 E-mail: support.asia@vitrolife.com www.vitrolife.com


<u>中文</u>	预防措施	准备培养皿	产品主要结构组成		
适用范围	由于从冲洗孔中无法采集图像、请勿使用此类孔孵育胚胎。	一次准备一个培养皿、以尽量减少处理时间。在非加热工作台	上  本产品由聚苯乙烯制造、无涂层。		
胚胎培养皿 EmbryoSlide 适用于时差培养箱(型号:Version D)	储液槽和冲洗孔必须始终使用 1.4 ml IVF 级油的培养油层覆盖。 如此可防止培养基在培养过程中挥发。	操作、使用冷培养基和油。 1. 在无菌洁净层流罩内将培养皿从包袋中取出。	产品生产日期、失效日期及储存、运输条件		
中卵母细胞和胚胎的培养。 禁忌症	培养基的挥发将改变渗透压、从而影响胚胎发育。	<ol> <li>使用微量移液管(最大直径:200 µm)将所有微孔填满 养基。一个吸头的液体就足以填满所有微孔。在填充期间</li> </ol>			
未知。	在加载培养皿时、始终将其置于无菌洁净层流罩内。在加载和处 理培养皿时、注意降低任何油或培养基溢出的风险。	移液管的尖端必须接触到微孔的侧面。使填充液量稍微超 微孔容量。	出 储存条件:常温储存。 运输条件:常温运输。		
<b>目标用户</b> 接受 Vitrolife A/S 认证讲师培训的 IVF 诊所的胚胎学家、其他实	若在加载或处理培养皿时任何油或培养基不慎溢出培养皿、必须 将胚胎转移到新的培养皿中、以防止胚胎受到溢出物的不良影响。	<ol> <li>使用标准移液管立即将另外 25 µl 的培养基填充到每个孔<sup>r</sup> 务必以恒定并且不过快的速率、自移液管靠近微孔底部处 放培养液。</li> </ol>			
验室人员和诊所工作人员。	若有油溢出到储液槽外部的培养皿上、请用无绒纸巾轻轻擦除油 污。若培养皿盖上沾有油污、则须更换盖子。	<ol> <li>4. 使用 25 µl 培养基填充每个冲洗孔。</li> <li>5. 将 1.4 ml 经过认证的适用于 IVF 的油加载到储液槽中。</li> </ol>	名称:Vitrolife A/S 瑞利芙(丹麦)有限公司		
<b>目标患者群</b> 接受生育治疗的患者。	在处理过程中、微孔和冲洗孔中温度下降的幅度将存在轻微变 动:i)前 2 分钟:微孔中温度下降幅度小于 0.1 ℃、冲洗孔中大	所有培养孔和冲洗孔全部都被油层覆盖。为每个未注满培 基的培养孔或储液槽添加额外的油。	住所、生产地址: Jens Juuls Vej 16, 8260 Viby J, Denmark 生产许可证编号: CVR (DK) 27406793		
临床获益	约下降 0.7 ℃。 ii) 在 2 至 5 分钟之间:微孔中温度下降幅度约为 0.2 ℃、冲洗孔中约为 0.6 ℃。需在您的恒温台不断验证温度。	6. 用微量移液管将所有大气泡推至上方后去除。 7. 用盖子盖住培养皿并放置一晚上、以待平衡。	电话:+45 7221 7900 传真:+45 7221 7901		
<ul><li>・ 改善胚胎发育</li><li>・ 提高着床/妊娠率</li></ul>	如果在准备好培养皿后发现孔内或油层中存有气泡、则这些气泡 可能会阻挡相机光线、影响图像质量。在极少数情况下、气泡可	<ol> <li>6. 在立体显微镜下识别并去除所有气泡。</li> <li>9. 使用微量移液管将胚胎装入微孔的中心。</li> </ol>	代理人/售后服务单位名称、住所和联系方式		
• 降低流产率。	能会将胚胎从微孔底部挤出。	10. 将培养皿置于 EmbryoScope 培养箱中。 产品名称	名称:瑞利芙(北京)医疗器械有限公司 住所:北京市朝阳区广顺北大街 33 号院 1 号楼-3 层-3001 等		
限制条件和使用限制 EmbryoSlide 培养皿仅在 EmbryoScope 培养箱中使用、须由受	必须小心且较快速地去除所有气泡、以避免培养基蒸发。 注意不要在去除气泡时移走任何培养基。	<b>下</b> 胎培养皿。	[287]套内 9 层二单元 1001 室 005 号 邮编:100102		
训人员按本说明书中的说明进行操作。应将一切涉及培养皿严重 事故报告 Vitrolife 及用户所在成员国的主管部门。	完成该程序后、根据医疗危险废弃物的标准临床惯例丢弃该产品。	产品型号及规格	电话: +86 10 64036613 传真: +86 10 64036613		
EmbryoSlide 培养皿和盖子是无菌的。包装袋只能在无菌洁净层	产品说明	型号、规格: FT-S-ES-D、EmbryoSlide。	E-mail: support.asia@vitrolife.com		
流罩中打开、且使用时必须盖好培养皿盖。 <b>警告和预防措施</b>	EmbryoSlide 培养皿是一种一次性使用的无菌培养皿、用于在 EmbryoScope 培养箱中培养胚胎。	产品注册证及技术要求编号	www.vitrolife.com		
客百41项附 <b>拍</b> 施 警告	EmbryoSlide 培养皿包含两类孔:12 个培养孔(胚胎在培养期间 放置其中)和 4 个冲洗孔(用于冲洗和处理胚胎)。胚胎位于每	医疗器械注册证编号:国械注进 20202180348 产品技术要求编号:国械注进 20202180348			
EmbryoSlide 培养皿仅供一次性使用、不得重复使用。用户对培 养皿进行清洗和再消毒的任何尝试都可能导致微生物污染或其他 设备故障的风险。	个培养孔内的中心凹陷处(微孔)。培养孔为圆柱形、直径为 4.09 mm。微孔为圆锥形、底部平整且直径为 0.25 mm。有关培 养皿的概述、请参阅本说明书最后一页的相关说明。	<b>产品性能</b> 无菌 SAL 10 <sup>-6</sup>			
	加加加加加。用空间平加的口服口,仅即用人加的。		—		
为避免微生物污染、在加载培养皿和对其进行一般操作时、始终 将培养皿置于无菌洁净层流罩中。		体外鼠胚试验(1-细胞鼠胚)[第5天扩张囊胚%] ≥ 80%	_		

每个批号的质检分析报告随货提供。

当胚胎转移到新设备或患者体内时、请始终将培养皿上的标签加 贴妥善并进行确认。

2

Symbol	Title	Description	描述	
REF	<b>Catalogue number</b> ISO 15223-1:2021 5.1.6	Indicates the manufacturer's catalogue number so that the medical device can be identified.	表示制造商的目录编号、以便识别医疗设备。	
LOT	Batch code ISO 15223-1:2021 5.1.5	Indicates the manufacturer's batch code so that the batch or lot can be identified.	表示制造商的批次代码、以便识别批次。	
	Use by date ISO 15223-1:2021 5.1.4	Indicates the date after which the medical device is not to be used.	表示不能再使用该医疗设备的日期。	
$\otimes$	<b>Do not re-use</b> ISO 15223-1:2021 5.4.2	Indicates a medical device that is intended for one use or for use on a single patient during a single procedure.	表示某个医疗设备为一次性使用、或在一个手术中单独用于某个患者。	
	<b>Do not use if packaging is damaged</b> ISO 15223-1:2021 5.2.8	Indicates a device that should not be used if the package has been damaged or opened.	表示某个医疗设备如果包装损坏或打开、则不能使用。	
<b>C E</b> 2460	CE mark	Declaration by the manufacturer that the device meets all applicable requirements in the Medical Device Regulation (EU) 2017/745.	制造商声明该设备符合医疗器械法规(欧盟)2017/745 中的所有适用要求。	
STERILE R	Sterilised using irradiation ISO 15223-1:2021 5.2.4	Indicates a medical device that has been sterilised using irradiation.	表示医疗设备已辐射消毒。	
Ĩ	Consult the instructions for use ISO 15223-1:2021 5.4.3	Indicates the need for the user to consult the instructions for use.	表示用户需要查阅使用说明。	
X	Temperature limit ISO 15223-1:2021 5.3.7	Indicates the temperature limits to which the medical device can be safely exposed.	表示医疗设备可以安全暴露的温度范围。	
	Manufacturer ISO 15223-1:2021 5.1.1	Indicates the medical device manufacturer.	表示医疗设备的制造商。	
~~~	<b>Date of manufacture</b> ISO 15223-1:2021 5.1.3	Indicates the date when the medical device was manufactured.	表示医疗设备的制造日期。	
MD	Medical device ISO 15223-1:2021 5.7.7	Indicates that the device is a medical device.	表示该设备是医疗器械。	
UDI	Unique device identifier ISO 15223-1:2021 5.7.10	Indicates a carrier that contains unique device identifier information.	表示包含唯一设备标识信息的载体。	



No.	1	2	3	4	5	6	7	8	9
English	Reservoir	Microwell	Label tab	Rinsing well	Well	Rinsing well	Handle	Microwell	Well
中文	储油孔	微孔	标签	冲洗孔	培养孔	冲洗孔	手柄	微孔	培养孔

# **Technical support**

Tel.: +45 7023 0500 E-mail: support.embryoscope@vitrolife.com www.vitrolife.com



Vitrolife A/S Jens Juuls Vej 16 DK-8260 Viby J Tel.: +45 7221 7900



4